

How to Install and Configure DD Free Dish to Receive Transmission on SWAYAMPBABHA Channels?

Two-step process for configuring and installing DD Free Dish and Set-top box, generally available with all TV dealers for less than Rs. 2,000/-, is as follows:

Step 1:

Install DD Fresh Dish as per the directions given at: [http://ddindia.gov.in/Technical/Pages/DD-Free-Dish-\(DTH\).aspx](http://ddindia.gov.in/Technical/Pages/DD-Free-Dish-(DTH).aspx)

Step 2:

Set following parameters in the Set-top box for SWAYAM PRABHA Channels:

a) Parameters for SWAYAM PRABHA channel No.1 to 17:

Satellite: GSAT 15(93.5 degree East)
Receive/: Downlink Frequency: 11590MHz
Symbol Rate: 29500KSPS
Polarity: Vertical

b) Parameters for SWAYAM PRABHA channel No. 18 to 34:

Satellite: - GSAT 15(93.5 degree East)
Receive/ Downlink Frequency:- 11670MHz
Symbol Rate: - 29500KSPS
Polarity: - Vertical